



**Systems Research & Technology Department  
CBR Science & Technology Branch, B54  
Special Projects and Systems Engineering Section**



# **New and Novel Technologies in Particulate Filtration**

**Mr. John Larzelere**

**November 20, 2003**

**Systems Research & Technology Department  
Chemical Biological Radiological Science & Technology Branch, B54  
Special Projects and Systems Engineering Section**

John Larzelere

540-653-3321

FAX 540-653-8747

Email: [LarzelereJC@NSWC.NAVY.MIL](mailto:LarzelereJC@NSWC.NAVY.MIL)

Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE <b>01 OCT 2005</b>		2. REPORT TYPE <b>N/A</b>		3. DATES COVERED <b>-</b>	
4. TITLE AND SUBTITLE <b>New and Novel Technologies in Particulate Filtration</b>				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) <b>Naval Surface Warfare Center, Dahlgren Division</b>				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT <b>Approved for public release, distribution unlimited</b>					
13. SUPPLEMENTARY NOTES <b>See also ADM001851, Proceedings of the 2003 Joint Service Scientific Conference on Chemical &amp; Biological Defense Research, 17-20 November 2003. , The original document contains color images.</b>					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT <b>UU</b>	18. NUMBER OF PAGES <b>24</b>	19a. NAME OF RESPONSIBLE PERSON
a. REPORT <b>unclassified</b>	b. ABSTRACT <b>unclassified</b>	c. THIS PAGE <b>unclassified</b>			

# **Why should we look at particulate filtration improvements?**

## **Old goals are not yet achieved**

- Provides ZERO pressure drop
- Is self cleaning and never loads up
- Never needs to be changed
- Occupies no more than 1/10 cubic inch of space
- Is weightless – but certainly no more than a few micrograms
- Is undetectable by any method – invisible


## **Research is changing paradigms**

## **Testing is revealing areas for improvement**

Paradigms must change as we learn new information. Perhaps the best known is the food group pyramid

1980

Four food groups




New Knowledge = Paradigm Shift



2003




Seven food groups



Its amazing to see the nutritional expertise a ten year old has the day after Halloween when they can recite the daily recommended allowance for candy.

**“Anything below 0.3 $\mu$ m is  
breathed back out”!**


This old paradigm was supported by  
limited research, testing, evaluation,  
and modeling tools.



Just as our understanding of nutritional requirements have changed, our understanding of particulate retention in the lungs has changed.

We have the obligation to take this new knowledge and evaluate it relative to each of our respective fields of study and determine what impact this will have on dependent and interrelated technologies as well as their foundational theories.

In many cases there may be no impact, but in some, such as epidemiology, toxicology, biological dispersion modeling and simulation, war gaming theory, and filtration issues, there might.



Schlesinger, Richard B., Ben-Jebria, A., Dahl, Alan R., Snipes, M. B., and Ultman, J., Disposition of inhaled Toxicants, *CRC Handbook of Human Toxicology*, p12, CRC Press LLC, 1999



# **Primary Drivers for New Media Development**

**Lower Energy Consumption**

**Longer Filter Life**


**Reducing the contamination threat posed by bio agent  
exposed media**

**Higher Dust Load Capability**


**Toxic Industrial Chemicals**

**Regenerative Capabilities**


## Interception



## Inertial Impaction




## Diffusion



## Physics of Fiber Filtration

conditions: 1.0  $\mu\text{m}$  fiber radius;  
0.1 packing density; 10 cm/s air velocity





# Particulate filter technologies of interest

## **New Filter Materials**

**Composite Materials**

**Irregularly shaped fibers**

**Nanofibers**

## **New Filtration Concepts**

**Electrically enhanced filters**

**Sacrificial prefilters**

**Electrostatic Precipitation**

**Regenerable Filters**


## **New and in progress Filter Assessment and Design Tools**

**Filter Media Design and Evaluation Model**

**CFD Flow Model**

Filter Material is typically a polymer and glass matrix


This media is used in all fixed sites, ships, and mobile land vehicles that use the M98 filter set.





## Micro-fiber Coating & Composite Material Technology:



- Technology being used and developed
  - Primarily focuses on polymer fibers.
  - Produce a bi-component fiber via an extrusion process. “Teflon like” material either as a coating or single fiber is a goal for chemical resistance enhancement. Teflon coatings of glass fibers using this method may not be possible.
  - Emerging technology is a coating technologies based on a plasma sublimation/condensation process for both polymer and glass micro-fibers, and electrospun materials.



Hills Inc. micrographs

## Irregularly Shaped Fiber Technology:

- Clemson University
- Hills Inc.



Used by permission of Dr. Edward Vaughn, Clemson University


## Fiber Fragmentation Process

**Extrude**

**Lay Down  
Fabric Base**

**Wash**

**Dry & Finish**





Hills Inc. micrograph






## Nano sized polymer fibers laid up over base filter material







## **Salt crystals captured by nano polymer fibers**



## Comparison of particle capture of standard filter material and standard material with nano fiber overlay




Images Courtesy of Timothy Grafe, Donaldson Company Inc.



## **NSWCDD spun nanofibers for DARPA funded effort**


**Significant since this is a “first off” for this process, which produced uniform fibers 0.2um in diameter.**

**Through better process control, significant diameter reduction may be possible.**




## Electrically Enhanced Filter Media

- Can use existing design configuration
- Provides for drastic increase in filter life
- Very low power consumption
- Alternate filter media options



Evaluate dendrite formation due to influence of electric field






## Sacrificial Prefilters

Existing  
Gas Filter


Existing  
HEPA Filter

Proposed  
Pre-Filter

**Slide in**



Proposed  
Pre-Filter




**Velcro or other  
attachment method**




## Porton Down UK Electrostatic Precipitation

**Roughing  
Filter**



**Electrostatic  
Grid**



**99%**

**HEPA  
Filter**



# Regenerative Particulate Removal

## • Humidity Control


- Reduced HVAC loading
- More predictable carbon filter performance
- Possible chem removal – i.e. reduced carbon bed size

## • Proven baseline HVAC

Technology which integrates novel particulate filtration technology

## • Integrated HVAC provides:




- Constant DP – no fan control
- Smoke removal capability
- Possible bio and rad particle concentrator – detection
- Decon issues reduced since disposable is contained in liquid suspension




Industrial Packed Tower Design

Initial computer model shows promise for predicting filter efficiency based on flat filter- 3D fiber matrix configuration, but more work is needed.

Computational Fluid Dynamics (CFD) will be used to analyze filter pleat geometry.



# What does all this mean?





**Systems Research & Technology Department**  
**CBR Science & Technology Branch, B54**  
**Special Projects and Systems Engineering Section**



# Acknowledgements

## **NSWC Dahlgren**

**Dr. Ken Tiedge**

**Aimee Dudash**

**Dr. Mark Greenfield**

**Doug Plotner**

**Jason Vui**

**Dr. Karen McGrady**

**Dr. Alfredo Rayms-Keller**

**Amanda Schilling**

**Dale Taylor**

**Jerry Brown**

**Larry Triola**

## **USAF**

**Bruce Nielson**

**Other supporting agencies, corporations,  
and individuals who have provided  
support and input:**

**Hills inc**

**Donaldson Corporation - Timothy Grafe**

**DARPA**

**NREL - Steve Slayzak**

**New World Associates – Dr. Tom VanDoren**

**NCSU**

**B.A.R.N. Engineering**

**Natural History Museum**

**Dr. Richard Schlesinger**

**Porton Down Chem Bio Laboratory**